

## ISTRUZIONI PER L'USO DEL SUPPORTO STRUMENTI BILANCIATO BALANCED TOOL SUPPORT INSTRUCTIONS FOR USE

Montare gli strumenti sul corpo del supporto, vedi esempio sotto.  
Unscrew all the four screws in order to remove the pre-installed handle



Immergere il supporto (con gli strumenti montati) nell'acqua dove si vuole effettuare l'immersione.  
Allentare la vite (1) fino a quando il coperchio (2) si apre e allagare l'interno del supporto fino a quando immergendo il tutto non si ottiene il galleggiamento desiderato.  
Fatto questo, assicurarsi che la vite (1) sia serrata a fondo senza forzare e inserire l'attacco (3) nell'apposita sede della maniglia dello scooter.  
Una volta effettuata l'immersione è consigliato svuotare il supporto e farlo asciugare.  
Non lubrificare gli OR di tenuta, ma assicurarsi solamente che siano puliti.

Submerge the support (with the instruments installed) in the water where you want to dive.  
Loosen the screw (1) until the cover (2) opens and flood the support interior until the required float is achieved when fully submerged.  
Next, make sure the screw (1) is fully tightened without protruding and insert the clasp (3) in the specific housing on the scooter handle.  
Emptying and drying the support after dives is recommended.  
Do not lubricate the OR seals but only make sure they are clean.

